

How do I attach the PrivaScreen™ Blackout Privacy Filter to my tablet?

Last Modified on 04/18/2019 1:01 pm CDT

To install a PrivaScreen™ Blackout Privacy Filter to your tablet, it is important to first clean the surface of your device with the included cleaning cloth to ensure all fingerprints, grease and debris are wiped away. Next, apply the L-shaped corner adhesive strips to the four corners of your PrivaScreen™ Filter, removing the blue backing from each strip only after you apply it to the filter. Make sure you apply the corner strips to the side with the sticky note, not the side with the protective film. Then, align the PrivaScreen™ Filter with the bottom edge of the device and button(s), and slowly lay the rest of the filter into place, while pressing the corners to secure the strips. Remove the clear protective film from your filter by pulling the tab.
