

# May I use an extension cord with my shredder?

Last Modified on 11/08/2018 2:43 pm CST

Your shredder must be plugged into a properly grounded wall outlet or socket of the voltage and amperage designated on the label. The grounded outlet or socket must be installed near the equipment and easily accessible. Energy converters, transformers, or extension cords should not be used with this product.

---