

What is the minimum size of desk required to successfully install the Lotus™ Sit Stand Workstation?

Last Modified on 06/07/2019 2:32 pm CDT

Lotus Sit Stand Workstation 0007901, 0009901 and Lotus DX Sit Stand Workstation 8080301, 8080201: The Lotus should be placed on a sturdy, flat surface at least 26.25" deep and 33.75" wide to have sufficient space for the product.

Lotus VE Sit Stand Workstation 8080101, 8082001: The Lotus VE should be placed on a sturdy, flat surface at least 24" deep and 28.75" wide to have sufficient space for the product. There are 3 depth adjustments which you can choose from when assembling the product. These allow the front edge of the work surface to sit flush with desk depths 23.6", 27.5" and 31.5".

Lotus RT Sit Stand Workstation 8081501, 8081601, 8081701, 8081801: The Lotus RT should be placed on a sturdy, flat surface at least 24" deep and 35" wide to have sufficient space for the product.