## What does the flashing and beeping mean on a UPS?

Last Modified on 04/05/2019 4:51 pm CDT

A slow beep and flash means that the battery is in use and will slowly increase as the battery wears down. A rapid beep and flash when you first plug in your devices to be backed-up means that you are drawing too much power from that unit.