

# I can't raise the blade to cut materials on my Fusion™ 120, Fusion™ 180, Plasma™ 150 or Plasma™ 180 cutter.

Last Modified on 04/08/2019 10:07 am CDT

To operate the Fusion™ 120, Fusion™ 180, Plasma™ 150 or Plasma™ 180 cutter, the SafeCut Guard must be completely upright.

If you are still having difficulty, please reach out to us by clicking on the Ask a Question tab above or calling our Customer Care Center at 1.800.945.4545, M-F, 7am-7pm CST.

---