

What causes my pages to look cloudy?

Last Modified on 05/25/2023 11:07 am CDT

Either the temperature is too low, or the combination of your pouch and document is too thick.

First, try passing your work through the laminator one or more times, or raising the temperature setting if your machine offers multiple heat options.

Otherwise, you should choose a thinner pouch, or reduce the weight or thickness of the documents you are trying to laminate.
