How do I change the Feather-Lift™ control paddle to display inches instead of centimeters?

Press and hold up and down at same time for 10 seconds.