

# The Levado table isn't level. How do I fix this?

Last Modified on 04/18/2019 10:33 am CDT

If the table feels unbalanced adjust the (4) levelling pads located on the bottom of the feet. Turn clockwise to lower and counter clockwise to raise.

## STEP 3

### Level Feet

- If table feels unbalanced adjust the (4) leveling pads located on bottom of feet
- Turn clockwise to lower and counterclockwise to raise

