

# My table top is smaller or larger than 60". How do I change the width of my Levado base to fit?

Last Modified on 04/18/2019 10:38 am CDT

Make sure your table top is face down on a soft, clean surface and place base on table. Use the 5mm Allen key to loosen the (8) set screws on the inward side of the cross channels. Expand or contract accordingly until the ends are flush with the table top. Re-secure the (8) set screws. Refer to step 1B in the instruction manual.

## **STEP 1B - Only required if table is not 60" (1524mm) wide**

Adjust the cross channels to their final lengths

- Use the 5mm Allen key to loosen the (8) set screws on the inward side of the cross channels.
- Expand or contract the cross channels until flush with both ends of the desk. Free cables as necessary to allow the frame to adjust.
- Once properly adjusted, use the 5mm Allen key to re-tighten the set screws (8 total).

